

CEE-BEE PAINT STRIPPER E-1058

by Cee-Bee®



d a t a s h e e t

CEE-BEE PAINT STRIPPER E-1058 is a non-toxic, thixotropic stripper specifically designed for removing polysulfide basecoat paint systems, polysulfide sealants and similar adhesives.

BENEFITS

- Contains no halogenated solvents, phenol, heavy metals or mercaptans.
- Provides excellent removal of polyurethane and other paint systems with polysulfide basecoats.
- Effectively removes polysulfide sealants and similar sealants, as well as natural rubber base sealants and coatings.
- Thixotropic. Clings to vertical, inclined and overhead surfaces.
- Free rinsing.
- Safe on all aircraft structural metals, including high strength steel.
- Surfactants are biodegradable.

CONFORMS TO

- GRUMMAN AEROSPACE GS115UT1
- T.O. 1-1-8, SECT.II

**NOTE: To place an order, call or FAX Customer Service at
800-932-7006 / FAX 1-216-441-1377
Cee-Bee Paint Stripper E-1058 Product Code # 23158**



NOTES PRIOR TO HANDLING

Before using your McGean-Rohco, Inc. products, all safety and operating instructions should be read and understood. If you have any questions, please contact your McGean-Rohco representative before proceeding.

USE PROCEDURES

Paint Removal

The surface to be stripped should be thoroughly clean and free from water.

1. Spray on a light coat of stripper using a high pressure 10:1 air activated pump equipped with a 1/2" I.D. high pressure hose and spray wand with a fan type spray nozzle.
2. It is important to use the correct type of spray nozzle for this application. A suitable nozzle is manufactured by Spraying Systems Co. Wheaton, Il. (708-665-5000), nozzle number 6508, fan-type.
3. Keep the surface wet with stripper until the paint buckles.
4. When the paint is lifted (one hour to overnight for tough coatings), brush the surface thoroughly to remove the loosened paint.
5. Reapply stripper as required to loosen any remaining paint.
6. When all of the paint has been lifted, use a brush or squeegee to remove the loosened paint and residual stripper.
7. Thoroughly rinse the surface with high pressure water.

Sealant Removal

1. The surface must be thoroughly clean and free from water.
2. Apply stripper with a brush and allow to dwell until the sealant is penetrated and dissolved. Apply additional stripper if required to keep the surface wet.
3. When the sealant is dissolved, remove with a suitable scraper that will not scratch the surface. Reapply Cee-Bee E-1058 to any spots of sealant not readily removed with the scraper.
4. When removal is complete, thoroughly rinse the surface with a water spray or wipe clean with cloths wet with water.

PROPERTIES

- Thick, clear, colorless liquid. Mild odor.
- Flash point, 212°F.

PRECAUTIONS

- May irritate eyes and skin - avoid contact. Use face shield, gloves and other protective clothing sufficient to prevent contact. Some form of eye protection is always absolutely essential. Concentrated vapors may cause irritation. Use in well ventilated area.
- Proper attention should always be paid to environmental considerations.
- In case of accidental contact with eyes or skin, flush area with water immediately. If irritation persists, seek medical attention.
- **DO NOT CONTAMINATE WITH WATER.** Water contamination will adversely effect stripping performance.